


Fuses, remove first!

water connection here (and on other side)



main connections are 13mm, small ones are torx

2 hold down bolts, 13mm (one on other side)

unplug signal connector